

General Instructions

# General Instructions and Inspection Instructions for Crane





R&M Materials Handling, Inc.  
 4501 Gateway Boulevard  
 Springfield, Ohio 45502  
 ☎ : (937) 328-5100  
 FAX: (937) 325-5319

EN R\_(EN)/1 -- 0936170401



**Read the instructions supplied with the hoist before installation and commissioning.**



Keep the instructions in a safe place for future reference.

Table of content

<b>1 Instructions.....</b>	<b>3</b>	2.3 Safety instructions for start-up of the hoist..	4
1.1 Symbols and abbreviations .....	3	2.4 Safety instructions for operating the hoist...	5
<b>2 Safety instructions .....</b>	<b>4</b>	2.5 Safety instructions for finishing work with the	7
2.1 Safety instructions for preparing to install		hoist	
the hoist .....	4	2.6 Safety instructions for servicing the hoist....	7
2.2 Safety instructions for installing the hoist....	4	<b>3 Crane inspection points .....</b>	<b>9</b>