
2 SCOPE AND PURPOSE

2.1 Scope

This Manual has been prepared by **R&M Materials Handling, Inc.** to provide recommendations for safe operation of **LoadMate® Series Electric Chain Hoists** with warnings against specific hazards so as to avoid personal injury and/or damage to property.

2.2 Purpose

It is the purpose of this manual to promote the adoption and use of uniform and effective safe operating practices for hoist operators. This manual also provides a ready reference for training, evaluation, and review of LoadMate® Series Electric Chain Hoist operating practices that are designed to assist in the prevention of personal injury and / or damage to property.

2.3 Installation and Maintenance Manual

The ELECTRIC CHAIN HOIST OPERATOR'S MANUAL and the ELECTRIC CHAIN HOIST INSTALLATION AND MAINTENANCE MANUAL are both provided with each **LoadMate® Series Electric Chain Hoist**. Both manuals are shipped with each unit from the factory. Both manuals SHALL be read prior to installation and operation in order to provide a safe environment and insure the proper care and maintenance of the product provided by **R&M Materials Handling, Inc.**