



4 HOIST OPERATION



BEFORE PROCEEDING WITH THE NORMAL OPERATION OF THIS HOIST, THE OPERATOR/(S) SHALL BE TRAINED IN ACCORDANCE WITH THE LoadMate® Electric Chain Hoist Operator's Manual AS SUPPLIED WITH THIS HOIST.

FAILURE TO READ AND COMPLY WITH ANY ONE OF THE LIMITATIONS NOTED IN THIS MANUAL AND THE LoadMate® Electric Chain Hoist Operator's Manual FURNISHED WITH THIS HOIST CAN RESULT IN PRODUCT FAILURE, SERIOUS BODILY INJURY OR DEATH, AND / OR PROPERTY DAMAGE.

REFER TO SECTION 1.0 OF THIS MANUAL FOR CONTACT INFORMATION IF YOU NEED ANY ADDITIONAL ASSISTANCE.