

English  
31.12.2008

# COMPLETE ASSEMBLY INSTRUCTION FOR CRANES

-  
-  
-  
-  
-





R&M Materials Handling, Inc.  
 4501 Gateway Boulevard  
 Springfield, Ohio 45502  
 P.: (937) 328-5100  
 FAX: (937) 325-5319



**Read the instructions supplied with the product before installation and commissioning.**



Keep the instructions in a safe place for future reference.

Table of content

<b>1 Crane components.....</b>	<b>4</b>	5.4 Low headroom hoist (drum diam. 303 mm or 355 mm), girder height >500 mm (Wire rope hoist) 30
1.1 Single girder crane (Wire rope hoist) .....	4	5.5 Low headroom hoist (drum diam. 406 mm) (Wire rope hoist).....
1.2 Double girder crane (Wire rope hoist).....	5	31
1.3 Double girder crane with a service platform (Wire rope hoist) .....	6	5.6 Double girder trolley (Wire rope hoist) .....
1.4 Single girder crane, underrunning end carriages (Wire rope hoist).....	7	32
1.5 Single girder crane (Chain hoist) .....	8	5.7 Normal headroom hoist (Chain hoist) .....
1.6 Solo hoist, pendant in festoon (Wire rope hoist) 9		33
1.7 Solo hoist, pendant fixed in hoist (Wire rope hoist) .....	10	<b>6 Traveling limit switch assembly.....</b>
<b>2 Festoon assembly.....</b>	<b>11</b>	6.1 Double girder trolley (Wire rope hoist) .....
2.1 Single girder crane (Wire rope hoist) .....	11	34
2.2 C-rail assembly of hoist power supply; Single girder crane (Wire rope hoist) .....	13	6.2 Normal headroom trolley (Wire rope hoist) 35
2.3 Single girder crane (Chain hoist) .....	14	6.3 Low headroom hoist (drum diam. 406 mm) (Wire rope hoist).....
2.4 C-rail assembly of hoist power supply; Single girder crane (Chain hoist) .....	16	36
2.5 Solo hoist with moveable pendant (Wire rope hoist) .....	17	6.4 Low headroom hoist (drum diam. 303 mm or 355 mm), girder height ≤ 500 mm (Wire rope hoist) 37
2.6 Solo hoist ,pendant fixed to hoist (Wire rope hoist) .....	18	6.5 Low headroom hoist (drum diam. 303 mm or 355 mm), girder height > 500 mm (Wire rope hoist) 38
2.7 Double girder crane (Wire rope hoist).....	19	6.6 Normal headroom trolley (Chain hoist) .....
<b>3 Traveling machinery assembly.....</b>	<b>21</b>	39
3.1 Machinery sizes 3-5.....	21	6.7 Crane limit switch assembly, top running end carriages .....
3.2 Machinery size 3, 8 wheels.....	22	40
3.3 Machinery size 3, 4 wheels.....	23	6.8 Crane limit switch assembly, underrunning end carriages (Wire rope hoist).....
3.4 Machinery size 2, 8 wheels.....	24	41
<b>4 Crane towing arm assembly.....</b>	<b>25</b>	<b>7 Bridge panel assembly .....</b>
4.1 Crane Towing Arm.....	25	42
4.2 Crane Towing Arm, 8 wheels end carriage and I-beam frame.....	26	7.1 Single girder crane (Wire rope hoist) .....
4.3 Crane Towing Arm, 4 wheels end carriage and 8 wheels end carriage with Hat-profile.....	27	42
<b>5 Hoist power towing arm assembly .....</b>	<b>28</b>	7.2 Double girder crane (Wire rope hoist).....
5.1 Normal headroom hoist, girder height ≤400 mm (Wire rope hoist) .....	28	43
5.2 Normal headroom hoist, girder height >400 mm (Wire rope hoist) .....	29	7.3 Double girder crane with a service platform (Wire rope hoist).....
5.3 Low headroom hoist (drum diam. 303 mm or 355 mm), girder height ≤500 mm (Wire rope hoist) 29		44
		7.4 Single girder crane (Chain hoist) .....
		45
		<b>8 Horn assembly.....</b>
		46
		8.1 Crane .....
		46
		8.2 Solo hoist .....
		47
		<b>9 Buffer stop assembly for single girder crane</b>
		<b>48</b>
		9.1 Wire rope hoist.....
		48
		9.2 Chain hoist.....
		49
		<b>10 Joint plate assembly .....</b>
		<b>50</b>
		10.1 Joint plate assembly, top running end carriages .....
		50
		10.2 Joint plate assembly, underrunning end carriages .....
		51
		<b>11 Load display assembly .....</b>
		<b>52</b>
		<b>12 Crane light assembly .....</b>
		<b>53</b>



R&M Materials Handling, Inc.  
4501 Gateway Boulevard  
Springfield, Ohio 45502  
P.: (937) 328-5100  
FAX: (937) 325-5319

12.1 I-Valo light, fixing to a flange of a main girder	53
12.2 Titano light, fixing to a flange of a main girder	54
<b>13 Flashing light assembly</b>	<b>55</b>
13.1 Flashing light assembly, top running end carriages	55
13.2 Flashing light assembly, underrunning end carriages	56
<b>14 Radio assembly</b>	<b>57</b>
<b>15 Radio assembly (solo)</b>	<b>58</b>
<b>16 Cable plugs and paths</b>	<b>59</b>
16.1 Single girder crane plug layout and cable paths (Wire rope hoist)	59
16.2 Single girder crane plug layout and cable paths, two hoists (Wire rope hoist)	60
16.3 Single girder crane plug layout and cable paths, three hoists (Wire rope hoist)	61
16.4 Double girder crane plug layout and cable paths (Wire rope hoist)	62
16.5 Double girder crane plug layout and cable paths, two hoists (Wire rope hoist)	63
16.6 Double girder crane plug layout and cable paths, three hoists (Wire rope hoist)	64
16.7 Plug diagram, (Wire rope hoist)	65
16.8 Plug diagram, two hoists (Wire rope hoist)	66
16.9 Plug diagram, three hoists (Wire rope hoist)	67
16.10 Single girder crane plug layout and cable paths (Chain hoist)	68
16.11 Plug diagram (Chain hoist)	69
16.12 Solo hoist with moveable pendant plug layout and cable paths (Wire rope hoist)	70
16.13 Solo hoist with fixed pendant plug layout and cable paths (Wire rope hoist)	71
16.14 Plug diagram, movable pendant (Wire rope hoist)	72
16.15 Plug diagram, fixed pendant (Wire rope hoist)	73
<b>17 Crane cable ways</b>	<b>74</b>
17.1 Assembly examples	74
17.2 Common assembly methods	75